

Re: How to handle 32 GB+ drives on a Win98 system

Source:

<http://www.tech-archive.net/Archive/Development/microsoft.public.win32.programmer.kernel/2006-12/msg00565.ht>

- *From:* "R. Wieser" <address@xxxxxxxxxxxxxx>
 - *Date:* Sat, 23 Dec 2006 02:21:52 +0100
-

Ben Voigt <rbv@xxxxxxxxxxxxxx> schreef in berichtnieuws
udU6uqeJHHA.960@xxxxxxxxxxxxxxxxxxxxxxxxxxxx

Hello Ben,
<snip>

As a result I'm posting this message, in which I (here it comes) want to ask if someone maybe has an idea to how I can get Windows to allow me to use the whole drive (an updated/special driver ? Other methods ? A (minimal) file-server solution perhaps ?), and/or what to look out for (so I can use the drive without worrying about loosing my data).

<snip>

Easiest solution -- boot a linux livecd, run fdisk, disk-druid, or your favorite other partitioning software that gets the partition table right, then reboot and use from windows.

Thanks for your answer.

It looks like, after rading Grzegorz and your answers, that I do not have to worry about that 32 GB border I keep reading about, so I'm going to give it a try. :-)

Regards,
Rudy Wieser