

sony network walkman(usb problem)

Source: <http://www.tech-archive.net/Archive/Mac/microsoft.public.mac.virtualpc/2004-11/0484.html>

From: John (*downtempo_rulez_at_mac.com*)

Date: 11/22/04

Date: 22 Nov 2004 14:11:58 -0800

Hi,

I have an NW-MS7 sony digital music player, wich is only compatible with windows. It uses flash memoy cards(sony memory sticks) wich are seen as outer storage by the computer(mac and pc). My problem is that the driver only works with windows, but OS X won't let the virtual pc see the flash memory card. It always recognises the player, but when I set VPC to use this usb device exclusively(so the mac doesn't see it) OS X tells me, that the usb device was disconnected improperly. What should I do to be able to use my sony with virtual pc?

thanks,

John