

Re: sony network walkman(usb problem)

Source: <http://www.tech-archive.net/Archive/Mac/microsoft.public.mac.virtualpc/2004-11/0487.html>

From: Robin Jackson (robinjackson_at_mac.com)

Date: 11/22/04

Date: Mon, 22 Nov 2004 22:23:30 +0000

What is it you are trying to do?

Put music on it?

If so why not get a card reader and mount the memory stick on the Mac via the card reader?

I do this all the time with the Memory stick in my Sony Ericsson Phone and Sony camera.

Robin

> *Hi,*

>

> *I have an NW-MS7 sony digital music player, wich is only compatible
> with windows. It uses flash memoy cards(sony memory sticks) wich are
> seen as outer storage by the computer(mac and pc). My problem is that
> the driver only works with windows, but OS X won't let the virtual pc
> see the flash memory card. It always recognises the player, but when I
> set VPC to use this usb device exclusively(so the mac doesn't see it)
> OS X tells me, that the usb device was disconnected improperly. What
> should I do to be able to use my sony with virtual pc?*

>

> *thanks,*

> *John*