

Re: Connected to Wifi but not to net

Source: <http://www.tech-archive.net/Archive/PocketPC/microsoft.public.pocketpc/2005-09/msg00531.html>

- *From:* "Helio Diamant – MS–MVP/Mobile Devices" <helio@xxxxxxxxxxxxxxxxxxxxxxxxxxxxx>
 - *Date:* Tue, 13 Sep 2005 18:02:03 +0300
-

This is usually what you see when your Wifi card is not activated or not inserted into the socket.

—

Helio Diamant
MS–MVP/Mobile Devices
www.pocketpcfreak.com

"Simon" <spambucket@xxxxxxxxxxx> wrote in message
news:3oo7n4F6n0onU1@xxxxxxxxxxxxxxxxxxxxx

>

>> Did you choose (when connecting) that you connect to Work or to The
>> Internet? If the first, you won't be able to get to the internet unless
>> you set a proxy.

>>

>> The remedy is to go to Settings | Connections | Network Cards, choose the
>> network by tapping on it, and when the options window opens, change the
>> Work option to The Internet.

>>

>

> Well, that's what the manual said, but it doesn't work :(.
> If I go to Settings | Connections | Network Cards I either have nothing in
> the drop down list or I have "Work",
> If I change the value to "Internet" and press OK it still does not work.
> If I go to check again, Settings | Connections | Network Cards the value
> has been set back to "Work".

>

> It doesn't want to change to "Internet", I tried many things, (even with
> the Wifi turned off), but it always remains at "Work".

>

> Regards

>

> Simon

>

.

Re: Connected to Wifi but not to net

- **References:**

- ◆ **Connected to Wifi but not to net**

- ◇ From: Simon

- ◆ **Re: Connected to Wifi but not to net**

- ◇ From: Helio Diamant – MS–MVP/Mobile Devices

- ◆ **Re: Connected to Wifi but not to net**

- ◇ From: Simon

- Prev by Date: **Re: Connected to Wifi but not to net**

- Next by Date: **"Hard" poweroff for PocketPC**

- Previous by thread: **Re: Connected to Wifi but not to net**

- Next by thread: **Restore default file icon for *.doc, *.xls etc file types.**

- Index(es):

- ◆ **Date**

- ◆ **Thread**