

Re: External CD-Rom Boot.

Source:

<http://www.tech-archive.net/Archive/Win2000/microsoft.public.win2000.hardware/2006-03/msg00020.html>

- *From:* William Asher <gcnp58@xxxxxxxxx>
 - *Date:* Tue, 14 Mar 2006 19:37:17 +0000 (UTC)
-

wrote:

My Problem-

I can not seem to find a way to boot my Toshiba Portege 3110CT off an external CD-Rom drive. I have to boot from an external do to the fact that this unit has NO built in Floppy or Cd-rom drive. I do on the other hand have both but external. Does anyone have any idea on a boot disk I can find online and or any information that can help me with this problem? Thanks.

D.Leas

On my Toshiba, I had to hit a particular key when it is at the Toshiba logo screen. I vaguely recall it being "c" but the F2 thing mentioned by Cari might work as well. If you bounce around the Toshiba support website you can find the info you need there as well.

--
Bill Asher

.