

Re: new notebook question

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.accessibility/2004-03/0063.html>

From: Eric Witte (ewitte_at_hotmail.com)

Date: 03/03/04

Date: 3 Mar 2004 06:47:05 -0800

"Nancy" <nbeyerle@comcast.net> wrote in message
news:<#qi4BpP8DHA.1592@TK2MSFTNGP10.phx.gbl>...
> *I hope this is the place for a question like this.*
> *I just bought a hp pavilion ze4600. I charged the battery. But when I use*
> *battery power the screen display is very dull. Is this a problem with the*
> *computer or the battery? Or is this normal? I am ready to take this*
> *computer back.*
> *Thanks for any answers because I am totally lost with these kinds of*
> *problems.*
> *Nancy*

Also you can Hold the Fn key and hit the f2 key. I do have one tip I learned from my ze4610. If its running extremely slow check power options and make sure it is at least on portable/laptop. Mine went into "presentation" mode while on battery. Which defaulted it to 519Mhz all the time. Portable/laptop adjusts due to demand.

Eric