

Re: multimedia audio controller

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.basics/2009-04/msg00348.html>

- *From:* "Rainy" <love_sweetz@xxxxxxxxxxx>
 - *Date:* Tue, 14 Apr 2009 11:46:29 -0400
-

also I installed the driver that came on the cd that came with the sound card.. everything installed correctly.. except for that errant Multimedia Audio Control.. I have tried the add new hardware and it doesn't find anything.. either from windows update or from the sound card cd.. Rainy "Don Phillipson" <e925@xxxxxxxxxxxxxxxx> wrote in message news:O8rhBfPvJHA.5708@xxxxxxxxxxxxxxxxxxxxxxxx "Rainy" <love_sweetz@xxxxxxxxxxx> wrote in message news:%23pXBwHKvJHA.1492@xxxxxxxxxxxxxxxxxxxxxxxx

Hi I just purchased and installed a new sound card.. A Creative Sound Blaster X FI Extreme Audio. (sounds great) Ok The reason I did was

because

I could never find the Multimedia Audio control for my very old creative sound card. and it didn't have the quality of sound I was looking for.

So

thinking that a new sound card would come with it's own Multimedia Audio Control, I was surprised to see the yellow exclamation point for my new

card

at Multimedia audio Control.. either this is old from the other sound

card,

or I have the same problem with the new card. :) does this make sense? .

.. .

If I need the multimedia audio control, where do I get it?
I have been to creative sound blaster website and put in search Multimedia audio Control and they don't have such a thing.. or.... I can't find it..

Re: multimedia audio controller

/ Control Panel / Multimedia is a component of the WinXP OS
(not of any particular sound card.)

Standard cure for hardware driver malfunctions is

1. Make a written note of the filepath to the right device driver.
2. In / Control Panel / System/
remove the device completely, then reboot.
3. In a standard installation, Windows should find the device
as "new hardware" and prompt you for the drivers, cf. #1.
The Registry may be preset to the wrong filepath (e.g. to
that for an audio device you have removed) but you can
/ Browse to the correct filepath.
4. If this does not work OK, you can use / Control Panel
/ Add Hardware and enter the data manually.

NB: If this motherboard ever had Sound on Board, you
should beforehand turn it off in the BIOS, so as not to
impede the new sound card.

Repost here with results.

—

Don Phillipson
Carlsbad Springs
(Ottawa, Canada)

.