

## usb port and driver

**Source:**

[http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.device\\_driver.dev/2004-09/0369.html](http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.device_driver.dev/2004-09/0369.html)

---

**From:** Brent Brien (*jetfan925\_at\_aol.com*)

**Date:** 09/26/04

Date: Sat, 25 Sep 2004 17:00:02 -0700

I know exactly what you are talking about. The same exact thing is happening to me with my HP Printer. I dont think it is neccassarily HP though because my palm pilot cradle did the same thing too. If you find out how to fix it or have already found out, can you email me at jetfan925@aol.com. Thanks.

>-----Original Message-----

>I get an error stsing that the USB device was not  
>recognized. I followed the help and the troubleshooting  
>from the computer and the web site.

>

>I have tried cd's that came with the HP camera .

NOthing

>came with the dock. This is the cable that the  
>instructions say to use. The cAMERA says it is  
connected

>to the computer. The computer does not recognize it. I  
>can download off the printer but why dioes the USB calbe  
>not work. I tried 2 different spots for the cable too  
>HELP!

>

>.

>