

NO sound

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2004-04/23171.html>

From: alittlesin (*anonymous_at_discussions.microsoft.com*)

Date: 04/26/04

Date: Sun, 25 Apr 2004 21:39:39 -0700

I've posted before, I'll try it again. I have no sound on my system. Sound card is on-board AC97. There are no error messages in the device manager, I've loaded the new driver from Microsoft updates (although the sound quit working before that). I've disabled in my BIOS, booted, shut down, re-enabled in my BIOS, re-booted, and still nothing. I've disabled the device in my device manager, booted, enabled, rebooted, and NOTHING changes. I'm not finding any system errors. I can't restore to an earlier date because the system says that restore could not go back, no changes made to the system.

I have a TV tuner in my computer, and when I plug into that I can hear the audio for the TV, but no system sounds there either. When I plug back into my soundcard, No TV or system sounds.

I've checked my registry, the HKEY all have the right settings (value not set).

I've done Start -> Run -> services.msc The audio is enabled there.

There are no fixes for my problem at Kelly's Korner. I've tried, and that ain't it.

Any help is appreciated. The only thing I can think of that may have happened in the between the sound working and not working is that I upgraded to Win Media Player 9. I think it was after that that it quit working.