

Re: CD Rom Whacked!

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2004-08/19228.html>

anonymous_at_discussions.microsoft.com

Date: 08/17/04

Date: Mon, 16 Aug 2004 20:40:26 -0700

>-----Original Message-----

>

> "David" <*anonymous@discussions.microsoft.com*> wrote in message

> *news:6aea01c48340\$9fad5920\$a601280a@phx.gbl...*

>>

>> *Need a bit of help on this guys and gals. I have a friend who can't install his Sims Deluxe on his Win XP Pro machine. He is using original CD's to do the install.*

>> *Here is what happens: Starts the install, moves along just fine. Prompted for second CD. Removes first CD and puts second CD in. CD Rom is reading this second CD as if*

>> *the first one was never taken out.*

>

> *Determined exactly how?*

>

>> *Tried CD Burner to do install. Same result. Installed just fine on different computer in the house.*

>> *Also noticed on programs that only had one disk for install, after installing the program and removing the disk, then putting a different program in to be installed*

>> *the CD rom was reading the disk as the one in which was just removed.*

>

> *Determined exactly how?*

>

>> *It seems as if the CD Rom is not refreshing*

>> *after removing a disc from it.*

>> *So what now? Drivers for CD Rom and Burner were updated. Didn't do anything.*

>

>

>.

microsoft.public.windowsxp.general: Re: CD Rom Whacked!

I when installing and removed first disk of install, then inserted second, it told me that it was the wrong disk. I then tried to use the second cr rom which the the cd burner. I used my computer to browse to it. That didn't work either, but I noticed that the my other drive (the original install drive) still said it contained Sims when in fact it was empty and the door was closed.