

Help: Disk is not accessible

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2004-11/10256.html>

From: Charlie Huang (*CharlieHuang_at_discussions.microsoft.com*)

Date: 11/15/04

Date: Sun, 14 Nov 2004 21:17:01 -0800

1. Maxtor 40Gb – partitioned into 2 drives
2. Maxtor 40Gb – partitioned into 2 drives

These two hard drives are connected to the on board ATA133 RAID connectors, and was created an Array for Performance -> RAID 0 Stripe.

I was previously running Windows XP Professional and was able to read and write all 4 partitions without any problem. However, Since I reinstalled the XP Professional due to some other problems, one of the partition has become inaccessible. When going into the Disk properties, its file system shows RAW. and when going into the Disk Management, it shows up as Healthy Basic Partition with an NTFS File System.

I want to be able to access the data on the drive, is there any way I can fix this?

Thank you.