

# Something constantly hitting hard drive.

---

**Source:**

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2005-07/msg15438.html>

---

- *From:* Sharon <[Sharon@xxxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:Sharon@xxxxxxxxxxxxxxxxxxxxxxxxxxxxx)>
  - *Date:* Fri, 29 Jul 2005 11:47:01 -0700
- 

This is an older HP laptop (500mhz) running XP SP2. I have almost no software loaded, since it is used primarily as an internet browser on a wireless network and as a DVD player in our RV. About a week ago, while watching a DVD in the RV it suddenly started hesitating. (This is with no network, no modem connection, nothing) The hard drive light was coming on about every five seconds. I ran a virus scan, a spyware scan, shut down everything in the systray, went into task manager and shut down the virus program, even turned off system restore. I cannot figure out what is hitting the drive.

It had just played two DVD's flawlessly, then something started hitting the drive, and every time it would hit the drive, the DVD would hesitate.

Any suggestions would be appreciated.

Sharon

.

---

- Prev by Date: [\*Re: Validation\*](#)
- Next by Date: [\*Re: Should I delete this...\*](#)
- Previous by thread: [\*RE: win32k.sys stop error, blue screen\*](#)
- Next by thread: [\*Taskmanager – as a realtime process\*](#)
- Index(es):
  - ◆ [\*Date\*](#)
  - ◆ [\*Thread\*](#)