

# Error "There is No Disc in Drive" when writing text files to CD-RW

---

*Source:*

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2005-08/msg00923.html>

---

- *From:* Kkraft <[Kkraft@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:Kkraft@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx)>
  - *Date:* Sun, 31 Jul 2005 18:12:03 -0700
- 

I have been able to write text files to my CD-RW until recently which may be after I received and automatic update from XP. I am using the MS CD Writer, I receive the error "There is no disc in the drive" when selecting properties is shows that the Discs have no free space, these are all brand new out of the package discs. I had this problem previously immediately after I upgraded to XP SP2, MS provided an executable that I ran and corrected the problem. I have asked for assistance which I got for a time and then there was no response. I realize I may need to purchase a 3rd party CD creator software, but wanted to see if anyone had heard of this problem in the past. I can burn audio files with no problems using 3rd party software like itunes. I can read CD's just cannot write text files using the MS CD Writer. I appreciate any suggestions.--  
KKraft  
.

---

- *Follow-Ups:*
  - ◆ ***Re: Error "There is No Disc in Drive" when writing text files to CD-RW***
    - ◇ *From:* Kelly
  - ◆ ***Re: Error "There is No Disc in Drive" when writing text files to CD-RW***
    - ◇ *From:* Richard Urban [MVP]
- *Prev by Date:* ***Re: restart question MS vs msconfig***
- *Next by Date:* ***default sounds missing in xp***
- *Previous by thread:* ***Can't change Windows XP Home Default Font Size***
- *Next by thread:* ***Re: Error "There is No Disc in Drive" when writing text files to CD-RW***
- *Index(es):*
  - ◆ ***Date***
  - ◆ ***Thread***