

Re: My sound has gone quiet

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2005-09/msg07502.html>

- *From:* "Charlie Tame" <charlie@xxxxxxxx>
 - *Date:* Tue, 20 Sep 2005 22:16:17 -0500
-

Okay, you said "The various places".

Open up the sound controller you normally use and make sure the master control shows and the Wav controller shows. Some of these things work differently (depends on the card maker's driver software to some extent) but you have options you can set regarding what controls can be displayed and sometimes what setup of speakers you have.

Some newer cards have dual purpose jacks that can be input or output for bass speakers and so on, see if you can find any settings in that utility that may have been changed accidentally.

I'm sorry I can;t be more specific but my Asus Motherboard has this type of controller on it and one jack sometimes gets changed... are you sure there isn't an alternative jack just for speakers, it should not do any harm to try.

In some case there is a speakers jack which is always speakers and one that can be line in and line out – which will be the same as speakers if configured as "Out".

Hope this helps and does not add to the confusiuon.

Charlie

"Buster" <Buster@xxxxxxxxxxxxxxxxxxxxxxxxxxxx> wrote in message news:FA47D47A-9FA7-476D-AABF-625A86FDBE4D@xxxxxxxxxxxxxxxxxxxx

- > For what seems like no reason, my sound has goen quiet. I can still hear
- > sound but it's very quiet even on full volume. I have checked the various
- > places where you can change the sound settings and yes, the volume on the
- > speaker is turned up full.
- > Does anyone have any ideas please?
- > Thanks
- > Buster

.

- Prev by Date: [*Re: Is he gone?*](#)
- Next by Date: [*Re: Security Question*](#)
- Previous by thread: [*Active desktop opens all links in a new window?*](#)
- Next by thread: [*Logitech LX700 CD not insalling – Access Denied*](#)
- Index(es):
 - ◆ [*Date*](#)
 - ◆ [*Thread*](#)