

Re: Haunted CD drive

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2006-06/msg09896.html>

- *From:* "LVTravel" <noone@xxxxxxxxxxx>
 - *Date:* Fri, 30 Jun 2006 10:58:09 -0400
-

Also, make sure that there is not something stuck in the back part of the drive (a piece of paper sucked into the opening by the system fans) could also cause this to happen.

"Malke" <notreally@xxxxxxxxxxxxxxxx> wrote in message news:OuvyyQFnGHA.3656@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx

cashdeskmac wrote:

For some strange reason my CD drive keeps opening and closing by itself. This happens whether there is a disc inside or not.

Anyone know what is causing this?

A long time ago this was symptomatic of trojan infection, but I very much doubt that is your issue now as all modern antivirus programs would have protected you from this ancient malware.

The usual reason for your symptoms is that the drive is failing. Just replace it.

Malke

—

Elephant Boy Computers
www.elephantboycomputers.com
"Don't Panic!"
MS-MVP Windows – Shell/User