

Re: Compact Flash Card Reader No Pop Up Window

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2007-01/msg10671.html>

- *From:* Bob I <birelan@xxxxxxxxxx>
 - *Date:* Fri, 26 Jan 2007 11:17:26 -0600
-

Try a System restore to a date prior to yesterday? See Windows Start, Help and Support.

Hi Dee wrote:

I have had a compact flash card reader for years. Each time I plug it in to my USB port a window pops up giving my options (copy to file, view files etc.). Yesterday I used it and no window popped up. I tried a second one assuming a defect may have occurred. Nothing. I've rebooted more than a couple of times. Nothing. I'm thinking I may have disabled something. I am not very computer savvy therefore I don't know where to start looking. HELP