

Re: Trying to Create a RAID 0 volume

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2007-02/msg08221.html>

- *From:* "Dave Patrick" <DSPatrick@xxxxxxxxxxxxxxxxxxx>
 - *Date:* Sun, 25 Feb 2007 18:48:03 -0700
-

Looks like their web site is down right now but try asking them here.

<http://forum.abit-usa.com/>

--

Regards,

Dave PatrickPlease no email replies – reply in newsgroup.
Microsoft Certified Professional
Microsoft MVP [Windows]
<http://www.microsoft.com/protect>

"Stan Hilliard" wrote:

Thanks Dave. This is to make sure that I use the right drivers, as I have doubts.

My RAID controller bios title is: "ALi RAID Bios Setup Utility"

The driver floppy that I previously installed with F6 during XP Setup had a readme.txt file that says:

"This driver supports ULi SATA/RAID controller." ALi versus ULi — what is the difference?

It is for M5288.

That is what ABIT technical service told me to use. I'm not sure that I told him that I was using RAID though.

Another driver file that he told me to install after installing Windows contains a readme.txt that says: "This driver supports ALi ATA/RAID Controller and SATA/RAID controller."

It is for M5289. What is the difference, M5288 and M5289?

I am wondering if I previously used the wrong item.

Re: Trying to Create a RAID 0 volume