

## Re: DVD-RW shows up as CD Drive in Windows Explorer (WinXp)

---

*Source:*

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2008-05/msg04693.html>

---

- *From:* Wisconsin Help? <[WisconsinHelp@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:WisconsinHelp@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx)>
  - *Date:* Wed, 14 May 2008 06:20:01 -0700
- 

I did delete the filters and restarted the system and that did not help.

I will try pulling the jumper setting off the back since I no longer am using the slave drive... or am I better off re-connecting my slave drive (which is a standard cd burner).

THanks for all the help!

"David Webb" wrote:

Did you restart the computer after deleting? If not, try it and report back any change in Explorer.

"Wisconsin Help?" <[WisconsinHelp@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:WisconsinHelp@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx)> wrote in message [news:4C2B273B-988D-4EDB-979E-1E5866C38813@xxxxxxxxxxxxxxxxxxxx](mailto:news:4C2B273B-988D-4EDB-979E-1E5866C38813@xxxxxxxxxxxxxxxxxxxx)

I found that article on a website and there was only lowerfilters.bak and I deleted that with no avail.

"David Webb" wrote:

Check your registry for the presence of upper and lower filters per the article cited below. Delete if found.

<http://support.microsoft.com/?scid=kb%3Ben-us%3B314060&x=12&y=13>

"Wisconsin Help?" <[Wisconsin Help?@discussions.microsoft.com](mailto:WisconsinHelp@discussions.microsoft.com)> wrote in message [news:05C77BDE-37A2-4BA4-BE6D-78009DE16DF2@xxxxxxxxxxxxxxxxxxxx](mailto:news:05C77BDE-37A2-4BA4-BE6D-78009DE16DF2@xxxxxxxxxxxxxxxxxxxx)

Hey Gang,

Re: DVD-RW shows up as CD Drive in Windows Explorer (WinXp)

Long time reader, first time poster....

I normally would consider myself relatively computer saavy, however, I've got a problem that I haven't been able to fix... even after a complete and destructive WinXp Re-install.

I have 2 DVD Burners, one an external DVD burner and the other is a brand new Sony DRU-190A that are both showing up as CD Drives in Windows Explorer. However, with Nero, they show up as DVD Burners/Drives.

I am running Win Xp Media Center 2005 with a new, clean install. I need to fix this because I use the Media Center software to record shows during the week for work and from what I've been able to read, only Media Center can burn the recorded shows off of media center.

Is there some way of getting these 2 drives to recognize correctly? I've already uninstalled the drives from the Device Manager and they still didn't come back correctly.

Thanks all...