

## Re: Windows XP opening DVD writer?

---

*Source:*

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.general/2008-06/msg00648.html>

---

- *From:* "Colon Terminus" <[colon\\_terminus@xxxxxxxxxxxx](mailto:colon_terminus@xxxxxxxxxxxx)>
  - *Date:* Tue, 3 Jun 2008 15:32:34 -0400
- 

"rockape" <[rockape.3affr7@xxxxxxxxxxxxxxxxxxxx](mailto:rockape.3affr7@xxxxxxxxxxxxxxxxxxxx)> wrote in message  
[news:rockape.3affr7@xxxxxxxxxxxxxxxxxxxx](mailto:news:rockape.3affr7@xxxxxxxxxxxxxxxxxxxx)

I have windows XP Pro with all service packs installed. When winXP boots my Benq Lightscribe DVD writer opens on its own, is there a setting in windows that will stop this happening. It continues to open of its own accord when it wants too

What exactly do you mean by "opens on its own"?

Does the drive door open?

Does Windows open and display the contents of the DVD/CD that's in the drive?

The first is virus/malware, the second is expected behaviour.

--

Posted via NewsDemon.com - Premium Uncensored Newsgroup Service

----->>>>>><http://www.NewsDemon.com><<<<<<-----

Unlimited Access, Anonymous Accounts, Uncensored Broadband Access

.