

Internet Keyboard

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2004-03/2075.html>

From: david millward (*anonymous_at_discussions.microsoft.com*)

Date: 03/14/04

Date: Sun, 14 Mar 2004 05:52:42 -0800

After installation, when I reboot, there are repeated beeps and the password field fills. I cannot delete the characters but have to hit return so that I can attempt password entry. Once logged on, I still get repeated beeps when certain keys are pressed.

Using XP Pro