

DVD won't burn DVD Media!

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2004-05/0557.html>

From: Ed (*anonymous_at_discussions.microsoft.com*)

Date: 05/03/04

Date: Mon, 3 May 2004 16:38:59 -0700

I got a DVD burner and I'm having problems with it. It burns a CD normally, plays DVD videos and all but when I put a blank DVD in it it doesn't do anything, I mean, It tries to read it but finally stops and when I try to burn files or video on a blank dvd the program keeps saying to inserv a blank dvd in the drive but the dvd is already there! Here are my Burner and Blank DVDs Specs:

BURNER:

DVD-R Write Speed

4x

DVD-RW Rewrite Speed

2X

DVD Read Speed

12x

DVD Access Time

130 ms

Compatible Writable Media

CD-R

CD-RW

DVD-R

DVD-RW

Writing Modes

Disc-at-Once

Incremental Recording

Packet writing

Restricted overwriting

Session-at-Once

Track-at-Once

BLANK DVD MEDIA:

Format

DVD-R

Capacity

4.7GB

Write Speed

4x

microsoft.public.windowsxp.hardware: DVD won't burn DVD Media!

Quantity
25 Disks
Packaging
Spindle

PLEASE! HELP ME OUT!