

USB non responsive

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2004-06/4148.html>

From: Ehud (*anonymous_at_discussions.microsoft.com*)

Date: 06/29/04

Date: Tue, 29 Jun 2004 09:21:32 -0700

Hello,

I have 6 USB 2.0 ports on my machine and they all work according to the Device Manager, but when I plug a web camera nothing happens. Windows doesn't seem to "feel" that some new hardware is plugged in.

I tried to update the driver through the Mother board web site and still no change.

The web camera is fine (I checked it on another machine) and the USB ports have power in them (Tested it with a power indicator device).

Furthermore, it appears that the problem is only in the USB ports. I tried to plug a printer and windows detected it just fine.

If you can help me, I would be grateful.
Thank you.

B.T.W, I have a Asus p4b533 Mother board, 512M RAM, Pentium 4 2.4Ghz , Win XP Pro