

CD-RW drive stopped working

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2004-10/2763.html>

From: Franz (*Franz_at_discussions.microsoft.com*)

Date: 10/21/04

Date: Wed, 20 Oct 2004 19:15:05 -0700

Help needed! The other day my CR-RW (LITE-ON LTR-52327S) just stopped working. I cannot burn Cd's anymore. When I insert a blank disc it seems to read it for a short while and then nothing happens. Also when I insert an audio CD, for example, it doesn't recognise it/read it.

I have removed and installed the software (NERO) as well as the driver. I have not physically moved the PC so the drive couldn't have gotten damaged. I also went through the troubleshooting steps and nothing helped.

I am no computer genius so I urgently need help!!!