

## CD-RW Driver crashed(error code 39)

---

*Source:*

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2005-06/msg00473.html>

---

- *From:* "Primit Roy" <[PrimitRoy@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:PrimitRoy@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx)>
  - *Date:* Wed, 8 Jun 2005 22:10:01 -0700
- 

Hi there,

My CD-RW Driver has been crashed recently.

During erasing a rewritable CD with Nero InCD it suddenly stopped working after completeing the job 100%. I ended the program at that stage but after that I found that the CD-RW driver is damaged.

It is SONY CRX320E and has a built in driver but while uninstalling and reinstalling Windows cannot load the driver and shows error code 39(driver corrupted or missing).

How can I make it to work?Please help.

.

---

- *Follow-Ups:*
  - ◆ ***Re: CD-RW Driver crashed(error code 39)***
    - ◇ *From:* Thorsten Matzner
- Prev by Date: ***Re: Installing Memory Problem***
- Next by Date: ***Re: USB DEVICE NOT RECOGNIZED***
- Previous by thread: ***Installing Memory Problem***
- Next by thread: ***Re: CD-RW Driver crashed(error code 39)***
- Index(es):
  - ◆ ***Date***
  - ◆ ***Thread***