

RE: This might help!

RE: This might help!

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2005-07/msg01358.html>

- *From:* "Pramit Roy" <PramitRoy@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx>
 - *Date:* Wed, 20 Jul 2005 09:43:42 -0700
-

One thing more,
I had "Eject" option while drive was not ejected and "Load" option in place of "Eject" when ejected, not Eject/Load simultaneously.

Thank you.

—

Regards,
Pramit Roy

"Behnoud" wrote:

- > There might be Several causes in my sight.
- >
- > 1. Nero InCD [version 4.0.0.1 beta and above]: yes, InCD Actually loads
- > this handler into windows shell, I have no idea how. but if you want it I
- > will go through registry to find it for you. By the way, windows XP supports
- > UDF, both 1.02 and 1.5; if you use InCD and you cannot access disks formatted
- > you can change the UDF version in preferences to matching one. there are
- > many settings you should change to make disks acceptable by windows without
- > installing that 430 KB InCD reader.
- >
- > 2. Sometimes Nero Image Drive causes this, too. sometime when you activate
- > NID, it adds it self to windows shell, sometimes not. if so you will have a
- > Load button instead of Eject, or Load/Eject.
- >
- > 3. Virtual CD Manager: those this as well (and some others like Daemon Tools,
- > Alcohol 120% and CloneCD [4.2.1.3 and below]).
- >
- > 4. Some versions of ASPI include this option. these contain localized or
- > specific ASPI layers. original ASPI from adaptec has no such option.
- >
- > And something else, remember every CD-RW drive comes in a package, unless
- > you have bought it in Large packages. every package includes the drive
- > itself, screws, installation disks (including vendor's software (unless it's
- > a very old drive) and burning software like Nero or Easy CD Creator, in a
- > very professional drive nothing!, and of course any DVD software for combo or
- > DVD-ROM like PowerDVD), documentation, installation figures, and sometimes

RE: This might help!

RE: This might help!

- > empty CD-RW and/or CD-R, Manual Eject Pin, and so it must have an
- > installayion CD at least. did you yourself install the drive for the first
- > time or it came pre installed on your system? did you receive all these in
- > your package. check Sony.com for more information about what should be in
- > your package.
- >
- > Remember, every removable optical disk drive comes with no driver from
- > vendor. drivers are contained within windows installation package.
- >
- > Hope this helps,
- > Behnoud

• **References:**

- ◆ **Why no 'Load' option for cd?**

◇ From: Prमित Roy

- ◆ **This might help!**

◇ From: Behnoud

- Prev by Date: **Re: Logitech USB mouse won't scroll**
- Next by Date: **Re: Hard Drive questions**
- Previous by thread: **RE: This might help!**
- Next by thread: **RE: Why no 'Load' option for cd?**
- Index(es):
 - ◆ **Date**
 - ◆ **Thread**