

trouble with some CD-RW dISKS

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2005-09/msg00110.html>

- *From:* macroc <macroc.1uqsdq@xxxxxxxxxxxxx>
 - *Date:* Fri, 2 Sep 2005 15:43:17 +0000
-

I have been sucessfully using both CD-R and CD-RW disks for about a year now. All of a sudden I cannot write to the CD-RW disks. No problem with the CD-Rs . Someone said that perhaps I ought to format the disks but when I follow instructions found in WORD help. I don't have the correct commands. Does anyone know what I might have done to cause this problem?
Help!!

—
macroc
.

- *Follow-Ups:*
 - ◆ **[Re: trouble with some CD-RW dISKS](#)**
◇ *From:* Bob I
 - ◆ **[Re: trouble with some CD-RW dISKS](#)**
◇ *From:* Andrew Murray
- Prev by Date: **[HDD \(sorry if wrong area.\)](#)**
- Next by Date: **[trouble with some CD-RW dISKS](#)**
- Previous by thread: **[HDD \(sorry if wrong area.\)](#)**
- Next by thread: **[Re: trouble with some CD-RW dISKS](#)**
- Index(es):
 - ◆ **[Date](#)**
 - ◆ **[Thread](#)**