

USB Mass Storage Problem

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2005-11/msg00120.html>

- *From:* donald1225 <donald1225.1xygax@xxxxxxxxxxxxx>
 - *Date:* Fri, 4 Nov 2005 03:36:51 +0000
-

My problem is that when I plug in any type of USB mass storage device – digital camera or thumbdrive I never get the message "finding new hardware". But I can see the device fine. I can open the drive, retrieve or store files, etc., etc. However I cannot unplug the device. Whenever I attempt this will get a fatal (blue screen) error and have to restart the system. Other USB devices work fine. Any help is most appreciated.

—
donald1225
.

- Prev by Date: [***Re: Is XP accessing both CPU cores?***](#)
- Next by Date: [***Re: Changing Mobo/CPU, want to keep current install***](#)
- Previous by thread: [***Re: 160GB partition shown as 100MB ???***](#)
- Next by thread: [***Data Drive Formatted – Can it be recovered?***](#)
- Index(es):
 - ◆ [***Date***](#)
 - ◆ [***Thread***](#)