

# burner not reading disks

---

*Source:*

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.hardware/2008-05/msg00190.html>

---

- *From:* "Windwatcher" <[whoozit@xxxxxxxx](mailto:whoozit@xxxxxxxx)>
  - *Date:* Mon, 5 May 2008 12:04:04 -0700
- 

I have a Memorex 510L DVD burner running on XP Home, and it's now saying the drive is "not accessible incorrect function. I notice that it's listed as DVD+RAM in Device Manager but it's DVD-RW drive in My Computer. Acronis and INTI Backup also see it as a DVD RAM.

Apparently some apps want it to use a DVD RAM disk. How do I get it back to the way it's supposed to be? Thanks for help....