

What is a Code 19 Error???

Source:

http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.help_and_support/2004-05/11384.html

From: NightFlyer (*anonymous_at_discussions.microsoft.com*)

Date: 05/30/04

Date: Sun, 30 May 2004 15:01:03 -0700

My DVD/CD-ROM drive wont work. Received the following error message.

Windows cannot start this hardware device because its configuration information (in the registry) is incomplete or damaged. (Code 19)

I can't load anything from CD, of course. Please help!!