

# Re: Memory

---

*Source:*

[http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.help\\_and\\_support/2007-10/msg00128.htm](http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.help_and_support/2007-10/msg00128.htm)

---

- *From:* "Mike Hall – MVP" <[mikehall@xxxxxxx](mailto:mikehall@xxxxxxx)>
  - *Date:* Tue, 2 Oct 2007 07:33:37 -0400
- 

Highlight and right click 'My Computer'. Select properties. The window should show total installed RAM..

"Peter F" <[PeterF@xxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:PeterF@xxxxxxxxxxxxxxxxxxxxxxxxxxxx)> wrote in message  
[news:F0F899DB-28BF-423C-8841-870AF86EA83D@xxxxxxxxxxxxxxxxxxxx](mailto:news:F0F899DB-28BF-423C-8841-870AF86EA83D@xxxxxxxxxxxxxxxxxxxx)

Hi All,

I recently purchased some SDram 512mb Memory and inserted it with my other chip on my home PC. I then went to start --> run --> cmd and typed in mem. The results were exactly the same before i inserted the new memory chip.

Does anyone know what is wrong, can anyone give me a sight where i am able to check what type of Memory is in my machine – before i installed the new chip.

Any help would be greatly appreciated.

Regards.

—  
Flinty