

# Re: No sound after reinstall

---

*Source:*

[http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.help\\_and\\_support/2009-06/msg02026.htm](http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.help_and_support/2009-06/msg02026.htm)

---

- *From:* "granjan" <[me@xxxxxxxxxxx](mailto:me@xxxxxxxxxxx)>
  - *Date:* Mon, 29 Jun 2009 18:36:50 -0500
- 

Thank you for the driver download site. I will keep that handy.  
I have already checked all those settings and more, but thanks for  
the help.  
Janice

"nass" <[nass@xxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:nass@xxxxxxxxxxxxxxxxxxxxxxxxxxxx)> wrote in message  
[news:032F0CA7-0AC3-413B-8AC8-B8D1A4B29891@xxxxxxxxxxxxxxxxxxxx](mailto:news:032F0CA7-0AC3-413B-8AC8-B8D1A4B29891@xxxxxxxxxxxxxxxxxxxx)

|  
|  
| "granjan" wrote:  
|  
| > I recently installed a new Seagate 500 gb sata hard drive and  
| > reinstalled WinXP Home on my daughter's computer. This replaced  
| an80  
| > gb Seagate sata. I also removed a Soundblaster Audigy sound card  
| > which came on the computer because she said it sounded garbled  
| > (whatever that means). I had a Mad Dog Multimedia Predator 5.1  
| that  
| > I had removed from an older computer that I gave away. It says  
| > compatible with xp and I have the installation disk. I  
| uninstalled  
| > all reference to Soundblaster. She has 5.1 surround sound  
| speaker  
| > set that came with her computer. Now there is absolutely no  
| sound  
| > coming from her computer at all. So far I have checked every  
| setting  
| > that I can think of with no luck. All volumes are turned up, it  
| > shows up in device manager with no error, I have uninstalled and  
| > reinstalled the card and drivers. I have checked the plugs and  
| all  
| > connections for the speakers. When I installed the card  
| originally I  
| > had her computer connected to an extra monitor which had  
| integrated  
| > speakers and there was no sound problem. I am beginning to think  
| her

Re: No sound after reinstall

| > speakers are bad but haven't tested them on any other computer yet.

| > I'm hoping there is a simple solution to this. Anybody?

| >

| > Janice

| >

| > Dell XPS gen2 computer

| >

| > WinXP Home (sp3 installed by cd from Microsoft that I had)

| >

|

| Make sure the sound Card fitted properly on the Slot and if there is a data

| cable make sure is connected to the Motherboard where it should be!

|

| Click Start >> Control Panel>> Sound, Speech, and Audio Devices.

| What can you see here?

| You will see three or more Icons/Applets, try to click on the Sound Icon for

| your Wizard and see if the wizard will be of a help.

| Another two icons, speech and Sound and Audio Devices, please click on the

| later to access the properties.

| You will see under Sounds and Audio Devices Props these Tabs.

| Volume | Sounds | Audio | Voice | Hardware

|

| Click On Volume and make sure the Mute not checked then click on the Speaker

| Volume Button and make sure the Slider selector set to High or you can Click

| on the advanced Button and see if the speaker listed there.

| On Voice tab make sure the device listed and your Microphone listed for an

| Input device.

| Hardware Tab make sure the device listed and been selected or try the

| troubleshoot Option.

|

| Here another download for the driver:

| [http://www.sound-drivers.org/?download=WinXP\\_2000.zip](http://www.sound-drivers.org/?download=WinXP_2000.zip)

| HTH,

| nass

| --

| <http://www.nasstec.co.uk>

|

|

|

|

|

|

|

|

|

|

|