

microsoft.public.windowsxp.music: MY CD-R drive wont recognize writable disks anymore

MY CD-R drive wont recognize writable disks anymore

Source: <http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.music/2005-02/0273.html>

From: agentDbleLxox (*agentDbleLxox_at_discussions.microsoft.com*)

Date: 02/11/05

Date: Fri, 11 Feb 2005 11:35:07 -0800

I used to be able to burn cds on my cd burner but i ran out of that particular brand on disks. Since then, i havent been able to burn any cds except CD-RWs (I used to have regular CD-R disks). However, these discs are not compatible with other operating systems and the information i put on them is wasted. Other blank CD-R discs are not even recognized when I insert them into my burner. How can I get my CD-RW drive to read the blank CD-R discs that I buy?