

Re: Volume control not responding correctly

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.music/2005-08/msg00009.html>

- *From:* "Chris Laarman" <larieONZIN@xxxxxxxxxx>
 - *Date:* Sat, 30 Jul 2005 20:53:20 +0200
-

ninerjhu (ninerjhu@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx) in
908738B1-3572-4E14-A60B-BAAD9746925D@xxxxxxxxxxxxxxxx:

- > I have looked for an answer to this problem but have not yet found
- > similar symptoms.
- >
- > I have recently installed iTunes, and am using a new USB driven
- > headphone device. Audio playback has worked following these changes
- > for sometime with no problems whatsoever.
- >
- > However, this morning suddenly the Speaker section of the Volume
- > Control panel for the USB device does not work properly. When I try
- > to 'push' the volume control up, after I 'unclick' the mouse the
- > volume setting slowly 'falls' down to zero. While it remains above
- > zero, the playback can be heard fine. And I can keep it playing by
- > continuing to 'push' the volume control back up, but ultimately it
- > always returns to zero.
- >
- > The controls work fine however for the Sigma Tel C-Major Audio (e.g.
- > my sound card).

No help, alas, but I have experienced something similar.

That was when using a resource-hungry software synthesizer. Its master-volume would sometimes be "magnetic" to the zero-level when I used its MIDI player.

I can't reproduce or test that no more, nor can I say if it could be a matter of CPU load or power (say powering USB-devices).

So JH, I'll join you in awaiting other answers. :-)

—

Chris Laarman

.

- **References:**

- ◆ **Volume control not responding correctly**

- ◇ *From: ninerjhu*

- Prev by Date: **HELP-- ... m4a ???**

- Next by Date: **RE: HELP-- ... m4a ???**

- Previous by thread: **Volume control not responding correctly**

- Next by thread: **HELP-- ... m4a ???**

- Index(es):

- ◆ **Date**

- ◆ **Thread**