

Re: realtek HD audio

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.newusers/2006-02/msg00103.html>

- *From:* "antioch" <r.antioch@xxxxxxxxxxxxx>
 - *Date:* Fri, 3 Feb 2006 11:27:45 -0000
-

Hello V

No Problem – I fully understand your situation.

My responses are spliced between your comments

"R..VENKATARAMAN" <venkat1926@xxxxxxxxxxxxxxxxxxxx> wrote in message
news:%23fTCImHKGHA.3932@xxxxxxxxxxxxxxxxxxxxxxxxxxxx

I am not an expert on hardware. this is only hand on experience.

"I'm the same."

as explained earlier as long as I use only one sound system in my case
yahoo messenger the checking of micvolume in mixer stays steady and I
could chat with my son through yahoo instnat messenger. As I do not use
any other system for recording it is ok for me. I dont want to tamper with
the drevers. I shall give your suggestion to my service engineer. In my
systems tray I have an icon for <realtek HD audio manager.

"Yes – I have the same"

If I click this I get four choice in the popupwindow

soundeffects/mixer/audio i/o/and some demo when for the firt time I was
talking to my son I was heraing his voice as if from a distance in a ghost
ridden huge hall. then by chance I went into sonnd effect in the audio
manager I find the selection was <concert hall> when I reset it to none I
could clerly hear my son's voice.

"If you still cant use the front mic jack try this. In that same popup
window(which should show your Mobo makers name)click on the Noise
suppression and Acoustic Echo buttons so they light up–click OK.
Then go into Audio I/O. In line with the word ANALOG you should see a
little spanner, white on blue. Click on that. Click on the box 'Disable
front panel jack detection'. Click OK. Exit the Realtek Manager.
Right click on the Realtek icon on the Taskbar instead of left click.

Re: realtek HD audio

You get 5 options, one of which is that same manager window.
Select Sound Recorder which should give you a small window Sound–Sound Recorder. Plug in the mic jack into the front.
Press the red button and start talking – the green line should show your voice level
Now with me this is where things go unexplained(so far).
I have to wait up to 30 sec before the line shows any movement.
Every time in the past I have tested but only for a few seconds then stopped thinking the mic is not working, when all the time it just needed to sort of warm up!!!!
If you then hit the stop button, hit rewind then hit play you should hear what you said."

any how for the present it is ok for me. I dont expect much help from the raltek company. anyhow thanks for your interest. I shall send the message to my service engineer.

Good luck
Antioch