

Re: Computer keeps restarting

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.newusers/2006-08/msg00215.html>

- *From:* "Bill Ridgeway" <info@xxxxxxxxxxxxxxxxxxxxxx>
 - *Date:* Tue, 25 Jul 2006 10:35:41 +0100
-

First your references to BIOS should be CMOS.

If all else fails you could reset the CMOS settings. To do this very carefully flip out the CMOS battery (a circular button battery mounted on the mother board) and leave out for several minutes before re-inserting. This should resolve any conflict you may have created by changing settings.

Regards.

Bill Ridgeway
Computer Solutions

<belovah@xxxxxxxxxx> wrote in message
news:1153813527.476702.165500@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx

Ok, so here's my problem.

I've recently decided to reinstall windows xp on my computer. So I made a backup of all important files that I have.

Then I formated partition D. Everything was ok.

Next thing I restarted my pc and put in cd-rom windows xp cd and got to the windows instalation screen but it wouldn't let me install them because harddrive couldn't be found(?). And it also said that there's maybe a problem with the floppy and it would be best to remove it. (something like that, i'm not sure)

So then I went to BIOS and I changed some settings. I set CD/DVD to primary master (before it was auto i think) and I disabled floppy.

Then I restarted my computer and it got to the boot screen where you can enter bios and you can see if the ram is ok...

But now I'm stuck there. It won't go any further and I can't even enter bios anymore. When I press F2 it only writes something like "go->bios" and then computer restarts.

Re: Computer keeps restarting

Can I make this work again? I just hope I didn't do anything fatal

Someone help me please, I'm kinda new around computers.

ps: sorry for my english