

why does my floppy drive get accessed at logon?

# why does my floppy drive get accessed at logon?

---

**Source:**

[http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.perform\\_maintain/2005-07/msg00277.htm](http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.perform_maintain/2005-07/msg00277.htm)

---

- *From:* sun <[sun@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:sun@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx)>
  - *Date:* Sun, 10 Jul 2005 07:21:03 -0700
- 

i am not talking about during boot as i have put harddrive as first in Bios. when i just reach the desktop, the floppy drive is accessed for a few seconds. i have reinstalled the floppy drive, checked there are no shortcuts to floppy drive files, and deselected 'check floppy drive' in norton antivirus. i have also removed all spyware and viruses using about 8 utilities.

what could it be?

.

---

- *Follow-Ups:*
  - ◆ ***RE: why does my floppy drive get accessed at logon?***
    - ◇ *From:* sun
  - ◆ ***Re: why does my floppy drive get accessed at logon?***
    - ◇ *From:* MAP
- Prev by Date: ***Re: XP Crash and lost admin access***
- Next by Date: ***Re: why does my floppy drive get accessed at logon?***
- Previous by thread: ***Spacing Errors***
- Next by thread: ***Re: why does my floppy drive get accessed at logon?***
- Index(es):
  - ◆ ***Date***
  - ◆ ***Thread***