

Re: playing a DVD

Source: <http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.video/2004-07/0360.html>

From: Cari \ (MS-MVP) (Newsgroups1_at_coribright.com)

Date: 07/10/04

Date: Sat, 10 Jul 2004 10:33:20 -0700

Go to the website of the notebook manufacturer, download and install updated graphics card drivers.

--

Cari

MS-MVP Windows Technologies - Printing/Imaging/Hardware

www.coribright.com

"DP Hunt" <DP.Hunt@discussions.microsoft.com> wrote in message

news:FE3140F4-1D02-436D-B9FE-7D8DC531193A@microsoft.com...

>I am trying to play a DVD on WinDVD2000 and I receive a message that says
>"creat Overlay Failed. Please lower your screen resolution or color depth
>and retry." I have lowered it to 600x800 and 16 bit and have rebooted a
>couple of times to no avail. Under Display Properties, I have gone into
>the settings tab and selected the advanced button - and gone to the monitor
>tab and the properties button is greyed out - as my PC is a laptop and
>there is only one monitor (the default).

>

> Does anyone know how to get this DVD player to work?

>

> DP

>