

Video Camera not recognized

Source:

<http://www.tech-archive.net/Archive/WinXP/microsoft.public.windowsxp.video/2005-08/msg00617.html>

- *From:* "DGD" <ddubowski@xxxxxxxxxx>
 - *Date:* 29 Aug 2005 17:28:29 -0700
-

I have a Canon ZR30MC digital video camera that for some reason is not recognized by Windows XP HE SP2. I have also downloaded the patch from the Windows Support site, but to no avail. Have tried to hook up the camera to three different computers (all running XP HE or PE) to no avail. The camera provides the "DV IN" message on the screen, but the computer simply doesn't recognize its existence. Have tried to eliminate the Windows Firewall from the 1394 port. The 1394 port on this computer is built into the mobo (Asus A7N8X-E Deluxe) so there is no firewire card. The device manager indicates everything is fine as well. Any help appreciated in trying to get this computer to recognize the video camera. Thanks.

DGD

.

- *Follow-Ups:*
 - ◆ ***Re: Video Camera not recognized***
 - ◇ *From:* Graham Hughes
- Prev by Date: ***Re: Movie Maker***
- Next by Date: ***HELP: No video***
- Previous by thread: ***Wierd Display Problem***
- Next by thread: ***Re: Video Camera not recognized***
- Index(es):
 - ◆ ***Date***
 - ◆ ***Thread***