

Re: Secondary Monitor

Source:

<http://www.tech-archive.net/Archive/Windows/microsoft.public.windows.mediacenter/2006-08/msg00411.html>

- *From:* "JW" <nospam@xxxxxxx>
 - *Date:* Tue, 18 Jul 2006 17:01:00 -0700
-

You are now running your secondary monitor in extended desktop mode instead of in clone mode. You can just drag and drop anything from you primary monitor over to the other other display which is probably on the right or left of your primary display edge.

"JTW" <JTW@xxxxxxxxxxxxxxxxxxxxxxxxxxxx> wrote in message
<news:FC45E0E5-5514-4F56-9CC5-F2B0459109AE@xxxxxxxxxxxxxxxxxxxx>

I am trying to connect my HP Media Center PC to a second monitor, which is really my SONY widescreen projection TV. It worked great when I preliminarily connected it the other day. Today when I connected the DVI to HDMI connections (i.e., PC output to TV input) via the same cable as before to install it more permanently, the sound was fine but the only picture I get is the background Desktop picture. There are no short cut icons on the desktop and no slies, programs or whatever show up on the TV. I have changed every primary and secondary characteristics setting on the screen I can think of to change and nothing works. I even tried making the TV the primary monitor and still nothing but the background picture of Windows or whatever I set it to be shows up. It even goes to screen saver after the set time interval. I can even change the desktop picture but no mouse arrow, icons or anything else show up. I have also tried an S-video connection with no better result. What have I messed up since it worked perfectly the other day? Please help. Thanks.