

Media Center WILL NOT use AC3 filter

Source:

<http://www.tech-archive.net/Archive/Windows/microsoft.public.windows.mediacenter/2006-11/msg00973.html>

- *From:* "revrenhex@xxxxxxxx" <revrenhex@xxxxxxxx>
 - *Date:* 15 Nov 2006 06:02:48 -0800
-

I have a ATI Theatre pro 550 (TV Wonder Elite), ATI Radeon 9800 vid card, onboard sound. I have installed AC3 filter, and set it as default. MCE will use AC3 filter when playing MP3's, and DVDs, but not live or recorded TV. If i play a recorded TV show outside of MCE using media player, it uses AC3 filter. How can I force MCE to use AC3 filter as the default for live/recorded TV?

.