

# Re: HELP!! NO AUDIO SOUND FOUND

---

*Source:*

<http://www.tech-archive.net/Archive/Windows/microsoft.public.windows.mediacenter/2007-04/msg00330.html>

---

- *From:* "AllanF" <[not.known@xxxxxxxxxxxxx](mailto:not.known@xxxxxxxxxxxxx)>
  - *Date:* Sat, 7 Apr 2007 13:31:57 +1000
- 

Hi k0oki3,

Something similar happened to me once.... volume icon and control just disappeared. Back then, I found a KB Article that stated something along the lines that "This can just happen!". A quick search found this (which I'm not sure is the same Article I found earlier, but may give you a lead): "Volume Icon Is Not Displayed in the Notification Area, and You Receive an Error Message When You Try to Add It", at:

<http://support.microsoft.com/kb/319095>

"k0oki3" <[k0oki3@xxxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:k0oki3@xxxxxxxxxxxxxxxxxxxxxxxxxxxxx)> wrote in message [news:FD00570E-5CDC-494D-ACE9-537BA13BD832@xxxxxxxxxxxxxxxxxxxxx](mailto:news:FD00570E-5CDC-494D-ACE9-537BA13BD832@xxxxxxxxxxxxxxxxxxxxx)

i have 3 problems going on with my computer rite now, but the one thats been bothering me the longest is my audio. i rebooted my comp early this week thinking it would be fixed but its not. whenever i try to play a song, it would say theres a problem with the audio and that its not working right. theres no volume control next to the clock on the lower right hand corner, and when i open the audio control from control panel, it says no audio device found. im so frustrated, i dont know what to do.

my computer is a T4510 eMachines, Microsoft Windows XP, Home Edition Preinstalled. please help, spring break is almost over for me and i need the sound to work in order to work on a interview documentary that's due in 2 weeks.