

SoundMax

Source: <http://www.tech-archive.net/Archive/Windows/microsoft.public.windowsupdate/2004-02/1023.html>

From: Jean (*anonymous_at_discussions.microsoft.com*)

Date: 02/06/04

Date: Fri, 6 Feb 2004 03:03:14 -0800

I am getting an icon on my taskbar saying No SoundMax present, and that I cannot use the SoundMax Control Panel. Can anyone assist me with this problem?