

# Re: nForce RAID Constant Install loop

---

*Source:*

<http://www.tech-archive.net/Archive/Windows/microsoft.public.windowsupdate/2007-12/msg00957.html>

---

- *From:* "realcestmoi" <[mdenie@xxxxxxxxxxxx](mailto:mdenie@xxxxxxxxxxxx)>
  - *Date:* Mon, 17 Dec 2007 09:33:02 +0100
- 

Hi there,

Never take drivers from windows update unless they are intended for Microsoft hardware.

If an updated driver is needed because the hardware does not work proper go to the manufacturers website to look for an updatede driver.

If it ain't broke: do not try to "FIX" it.

If you did take the optional drivers from windows update try booting last known good configuration, rolling back on the driver or system restore or restore from the system backup you hopefully made.

You can disable the update appearing by going to the windows update website and unmark (hide) the Nvidia Nforce driver.

Best regards,  
Michel Denie

"Larkin S" <[Larkin.S@xxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:Larkin.S@xxxxxxxxxxxxxxxxxxxxxxxxxxxx)> wrote in message [news:23558AAD-EA39-4028-9CCA-7E16B6CDF502@xxxxxxxxxxxxxxxxxxxx](mailto:news:23558AAD-EA39-4028-9CCA-7E16B6CDF502@xxxxxxxxxxxxxxxxxxxx)

So I recently updated my nForce Raid drivers and now whenever I boot up the computer it tries to install the drivers. The Controller always installs fine but when the 2 Devices try to install it says "Pending..." then I am asked to restart and no matter how many times I restart it always does the same thing. I even tried installing the drivers for nForce 680i SLI from the Nvidia site, that didn't help. Even the WU files I get the 80070103 error when I try to install them. Is there anyways I can fix this so that it doesn't keep popping up everytime I restart!

Re: nForce RAID Constant Install loop

I have 3 Seagate 80gb in RAID 0