

Re: CE 5.0 unable to read settings from the datastore

Source:

<http://www.tech-archive.net/Archive/WindowsCE/microsoft.public.windowsce.embedded/2008-04/msg00375.html>

- *From:* mike 1369 <mike1369@xxxxxxxxxxxxxxxxxxxxxxxxxxxxx>
 - *Date:* Thu, 24 Apr 2008 05:44:00 -0700
-

Hi Luca,

You got it: the Connectivity option appears now :-))

Many many thanks for your help !!!

"Luca Calligaris" wrote:

you should find a folder named ...\\Windows CE Platform
Builder\\5.00\\CORECON\\SCRIPTS.
try to run the batch files inside in this order:

```
disablecorecon  
unregister  
register  
enablecorecon
```

all of them need as an argument the full path to ...\\Windows CE Platform
Builder\\5.00

--

Luca Calligaris
www.eurotech.it

"mike 1369" <mike1369@xxxxxxxxxxxxxxxxxxxxxxxxxxxxx> ha scritto nel messaggio
news:912EDFAD-A580-4B2A-9487-4EEA5CE27F03@xxxxxxxxxxxxxxxxxxxxx

Hello all,

After a short evaluation of Windows CE 6.0, I finally had to install CE
5.0,
as the platform I could use had CE 5.0.
So I uninstalled CE 6.0 and Visual C 2005 Pro, then installed WinCE 5.0.

Re: CE 5.0 unable to read settings from the datastore

Here is my problem: the menu [Target] / [Connectivity Options] gives the following error : "platform builder was unable to read the device settings from the datastore"

I saw this note on the web :

<http://blogs.msdn.com/dcook/archive/2007/05/13/does-pb-5-0-work-side-by-side-with-pb-6-0.aspx>
but I have no "CoreCon" in my settings

Something is corrupted somewhere, but I can't find it

Thanks for your help