

## Re: PC104 Bus support

**Source:**

<http://www.tech-archive.net/Archive/WindowsCE/microsoft.public.windowsce.platbuilder/2004-05/0243.html>

---

**From:** Paul G. Tobey [eMVP] (*ptobey\_no\_spam\_at\_instrument\_no\_spam.com*)

**Date:** 05/06/04

Date: Thu, 6 May 2004 15:59:38 -0700

PC/104 is generally not 'enumerated' in the same way PCI is; it's just ISA (unless you mean PC/104+, which, as I recall, *\*is\** PCI. Most PC/104 cards have switches or jumpers to set what address, interrupt, etc. they use. You'll need a driver of some sort for your A/D card, but, assuming it's not some sort of ISA Plug-and-Play card that requires help from a bus driver to get set up, you shouldn't need anything but a driver for the card itself.

Paul T.

"SteveW" <steveDOTworchester@avnetDOTcom> wrote in message news:06503983-2338-489D-B435-049516F1D48C@microsoft.com...

> *If I have a PC104 bus on my CEPC, do I need a driver to support it? I see that I need one for items on the PCI bus, but I can't figure out the 104 stuff. I don't see it in the BSP I have.*

> *Would I also need a drive for an A/D card on the 104 BUS?*

> -TIA

> Steve