

## Re: unable to boot cepec from HD

**Source:**

<http://www.tech-archive.net/Archive/WindowsCE/microsoft.public.windowsce.platbuilder/2004-10/1370.html>

---

**From:** Sujith (*sujithss\_at\_hotmail.com*)

**Date:** 10/29/04

Date: Fri, 29 Oct 2004 10:37:01 +0530

post the error message may be some one can help.

Regards  
Sujith

"Radha Kumar Reddy" <RadhaKumarReddy@discussions.microsoft.com> wrote in message news:7E1F3B24-08AD-4C79-8D62-16ABF2D54F73@microsoft.com...

> *Thanks Sujith,*  
> *I tried to boot winCE from hard disk. I did what exactly was told in the*  
> *tutorial ->*  
> *created to disks ( setup and boot ) ,*  
> *formatted the HD,*  
> *setup the environment,*  
> *copied the files from bootdisk to HD,*  
> *copied the nk.bin by connecting this HD to another system as slave.*  
> *And made change in autoexec.bat to loadcepc nk.bin. ( I didnot give any*  
> *cmd*  
> *line options )*  
> *But when I boot the cepec, it gives the splash screen and jumps to blue*  
> *screen with some error number.*  
>  
> *I do not understand why it doesnot boot. I am left with no clues. any help*  
> *in this regard is of great appreciation.*  
>  
> *thnx.*  
> *Radha Kumar Reddy.*  
>  
> *"Sujith" wrote:*  
>  
> *Hi,*  
> *so basically it is downloading..*  
> *good. may be you can trap the debug messages using the other COM port*  
> *and*  
> *check-out what went wrong.*  
> *possible options could be.. the display driver should be the same as the*  
> *target machine.. not host machine..*  
> *more over are you able to get the machine id in the configure remote*

microsoft.public.windowsce.platbuilder: Re: unable to boot cepc from HD

- > > *connection, ethernet.settings..?*
- > > *if yes.. ok. if no.. add the correct driver for the device(ethernet). it*
- > > *should work at any cost..*
- > > *regards*
- > > *Sujith*
- > > *"Radha Kumar Reddy" <Radha Kumar Reddy@discussions.microsoft.*