

BLDR

Source:

<http://www.tech-archive.net/Archive/WindowsCE/microsoft.public.windowsce.platbuilder/2005-06/msg00518.html>

- *From:* "Dale" <Dale@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx>
 - *Date:* Sat, 11 Jun 2005 11:55:03 -0700
-

Hi All,

I am trying to load a WinCE 5.0 X86 CEPC BSP onto a standard PC. I am trying to boot from disk using the BIOS boot loader. When I reboot the system I get an error saying: "Unable to load BLDR!"

Here are the details:

To prepare the disk I am doing the following:

- 1) Create a setup disk using setupdisk.144.
- 2) Creating a 200 MB, active DOS partition using FDISK.
- 3) Using mkdisk to copy over the boot sector to the harddisk.
- 4) Copy the NK.bin over to the hard disk.

When I reboot the system I get the message displayed:
Microsoft Windows CE BIOS Bootloader
Unable to load BLDR!

I am monitoring the serial port but nothing is displayed.

Can someone please give me an idea of what might be wrong here?

Thanks,
Dale

.

- Prev by Date: [***Re: where can i download bsp for SA11X0BD***](#)
- Next by Date: [***Re: How to debug a device driver on a PPC?***](#)
- Previous by thread: [***How to debug a device driver on a PPC?***](#)
- Next by thread: [***NDIS Hook***](#)
- Index(es):
 - ◆ [***Date***](#)
 - ◆ [***Thread***](#)