

## Re: how do I update nk.bin ? HELP

---

*Source:*

<http://www.tech-archive.net/Archive/WindowsCE/microsoft.public.windowsce.platbuilder/2006-01/msg00663.html>

---

- *From:* "Henrik Viklund" <[henrik.viklund@xxxxxxxxxx](mailto:henrik.viklund@xxxxxxxxxx)>
  - *Date:* 17 Jan 2006 04:32:50 -0800
- 

There are many ways to do this, and what works best on one platform may not work at all on another, in other words, to get a reasonably intelligent answer you need to provide atleast some info on your specific platform. What BSP? How is the image stored on the device? Is it stored on a flash device? Is it stored in some kind of filesystem? is it a RAM- or ROM based image, etc?

Henrik Viklund

.

---

- *Follow-Ups:*
  - ◆ [\*\*Re: how do I update nk.bin ? HELP\*\*](#)  
◇ *From:* B.R.Liao
- *References:*
  - ◆ [\*\*how do I update nk.bin ? HELP\*\*](#)  
◇ *From:* B.R.Liao
- Prev by Date: [\*\*Re: Coredll patch Windows CE 4.21\*\*](#)
- Next by Date: [\*\*Re: how do I update nk.bin ? HELP\*\*](#)
- Previous by thread: [\*\*how do I update nk.bin ? HELP\*\*](#)
- Next by thread: [\*\*Re: how do I update nk.bin ? HELP\*\*](#)
- Index(es):
  - ◆ [\*\*Date\*\*](#)
  - ◆ [\*\*Thread\*\*](#)