

Re: Printer stops PC booting

Source:

<http://www.tech-archive.net/Archive/Windows/microsoft.public.windows.mediacenter/2005-12/msg00703.html>

- *From:* "Dana Cline – MVP" <dcline@xxxxxxxxxxxxxx>
 - *Date:* Wed, 7 Dec 2005 10:38:58 –0600
-

My first thought would be to poke around in the BIOS and see what USB port settings might be available to change. My second thought would be – if it's new, it's still under warranty, so let HP support fix it...

Dana Cline – MCE MVP

"wyv3rn" <wyv3rn@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx> wrote in message <news:858673CF-66DA-454F-BFDE-2D2EB728BAC9@xxxxxxxxxxxxxxxxxxxxxx>
> I have a new HP a1230n computer running MCE 2005, together with an HP PSC
> 2210 All-in-one printer connected thru USB.
> With the printer connected at boot time, the computer refuses to boot. The
> boot sequence just does not start, no XP splash screen or nothing.
> If I disconnect the printer, or simply leave it connected and power it
> down,
> the computer boots OK everytime. I can then connect the printer and it
> will
> work perfectly.
> I'm running the latest printer driver.
> Any ideas?

.

-
- Prev by Date: [***Re: Media Center edition has the same UI as XP Pro – How to change thi***](#)
 - Next by Date: [***Re: Monitor and LCD TV in one PC for diferrent uses***](#)
 - Previous by thread: [***Considering Media Center Computer -- Please Advise***](#)
 - Next by thread: [***Re: Printer stops PC booting***](#)
 - Index(es):
 - ◆ [***Date***](#)
 - ◆ [***Thread***](#)